



# Craven Equipment

Inspired by Adventure Built for Everyday

Bike – Royal Enfield Meteor

**This bike does not use a luggage rack**

This fitting kit can only carry panniers, it has no topbox rack.

**Included in the fitting kit:-**

Part Number	Quantity	DESCRIPTION
B114	4	Spacer 8x15x50mm
FA1439Q	4	Screw, cap head, hex socket, M8 x 25, stainless
FA1444Q	2	Screw, cap head, hex socket, M8 x 110, stainless
FA1530Q	4	Nyloc nut, M8, stainless
FA1604Q	2	Screw, cap head, hex socket, M8 x 100, stainless
P192	2	Side plates for RE Meteor
P485	2	Straight leg 7-3/16 centres
S19-3Q	12	Plain washer, 5/16, stainless

Firstly, remove the two bolts either side from under the pillion seat (see Fig 1)  
Using the cap head screws provided, attach the top holes of the side plate (P192) into these existing holes (110mm long screws are for the front, the 100mm screws for the rear). Spacers and washers should be used between the bike and the side plate.

Attach the straight leg (P485) to the pillion footrest lug behind each footrest (see Fig 1) using the new 25mm bolts and nuts provided. Then attach the other end of the leg to the desired place on the side plates, through the horizontal slots.  
When fitting luggage, make sure the indicators are not obscured from the sides.



# Craven Equipment

Inspired by Adventure Built for Everyday

**Fitting luggage** :- to fit luggage, please see our 'General Fittings' sheet. Contact us if yours is missing.

