



Craven Equipment

Inspired by Adventure Built for Everyday

Bike – BSA, D7/10/14/B175 & C15 1959-70

The correct rack for these bikes is a 'W' rack

The fitting kit is designed to mount the rack to the motorcycle. A secondary kit is required to hold panniers.

Included in the fitting kits:-

Main fitting kit

Part Number	Qty	Description
P399	2	Support arm BSA D7/10/14, Triumph T20B
P477	2	Straight leg 5-13/16 centres
P437	2	7/8 tube clip
P203	2	Support arm clamp, flat
P493	2	Flat bracket, twist to be inserted to suit bike
41-0146	2	Distance piece - stainless steel
FA1476Q	8	Set bolt, M8 x 20, stainless steel
FA1477Q	6	Set bolt, M8 x 25, stainless steel
FA1040Q	2	Bolt, standard head, M8 x 30 (1-1/4"), stainless
FA1530Q	16	Nyloc nut, M8, stainless
S19-3Q	32	Plain washer, 5/16, stainless
FA1026Q	2	Nut, thin, M8, stainless



Craven Equipment

Inspired by Adventure Built for Everyday

Pannier fitting kit

Part Number	Quantity	DESCRIPTION
FA1476Q	2	Set bolt, M8 x 20, stainless steel
FA1530Q	2	Nyloc nut, M8, stainless
P374	1	Support arm left hand BSA D7/10/14, Triumph T20B
P374A	1	Support arm right hand BSA D7/10/14, Triumph T20B
s19-3Q	4	Plain washer, 5/16, stainless

Fitting the rack:- Specific notes about your kit

Main kit

It is quite straightforward to fit the rack to the bike. Remove the seat and attach the loop stays as shown in Fig 1, using the spacers and fastening the two-holed top of the clamp brackets (P493) so they hang below. The white arrow shows which bolt uses the thin M8 nut. Then attach the long support arms (P399) to top shock absorber bolts, so the base of the 'L' faces up and toward the rear, as shown. Now attach the flat, straight supports (P477) to the long arms, drilling a hole to suit. Finally attach the rack to the two uprights of the support arms each side, and clamp the loop stays to the long support using the shorter clamp side (P204). Tighten all the nuts up equally, making sure to keep the rack level as you go.

Secondary fitting kit

This is only required to hold panniers. Remove the pillion footrest mounts. Attach the P374 & P374A long support arms to each side and refit the footrests. Using the nuts & bolts supplied, attach to the W rack along the outside edge against the skates on the bottom.

See 'General Fitting instructions' for step-by-step advice for fitting a rack and panniers to any machine.



Craven Equipment

Inspired by Adventure Built for Everyday

Fig 1





Craven Equipment

Inspired by Adventure Built for Everyday

Fig 2

