



# Craven Equipment

Inspired by Adventure    Built for Everyday

**Bike – Triumph T20 1957-66 (not Bantam Cubs)**

**The correct rack for these bikes is a 'W' rack**

The fitting kit is designed to mount the rack to the motorcycle. An additional kit is required to hold panniers.

**Included in the rack fitting kit:-**

| Part Numbers | Qty | Description                            |
|--------------|-----|--|
| 0510Q        | 2   | Bolt, 1/4CEI x 5/8, stainless steel    |
| FA1476Q      | 4   | Set bolt, M8 x 20, stainless steel     |
| FA1530Q      | 4   | Nyloc nut, M8, stainless               |
| P200         | 1   | Support arm for Triumph T20 right hand |
| P201         | 1   | Support arm for Triumph T20 left hand  |
| S1-2Q        | 2   | Nut 1/4 CEI26 - stainless              |
| S19-2Q       | 2   | Plain washer 1/4, stainless            |
| S19-3Q       | 8   | Plain washer, 5/16, stainless          |



# Craven Equipment

Inspired by Adventure    Built for Everyday

## **Pannier kit:-**

| Part Number | Quantity | DESCRIP                              |
|-------------|----------|--------------------------------------|
| FA1476Q     | 2        | Set bolt, M8 x 20, stainless steel   |
| FA1530Q     | 2        | Nyloc nut, M8, stainless             |
| P463        | 1        | Carrier arm Triumph T20 - right hand |
| P464        | 1        | Carrier arm Triumph T20 - left hand  |
| S19-3Q      | 4        | Plain washer, 5/16, stainless        |

Pannier fittings - See 'General Fitting instructions' for step-by-step advice

## **Fitting the rack:- Specific notes about your kit (see pictures over page)**

### **Main kit -**

Remove the seat from the bike. Remove the shock absorber top bolt on one side, then remove the bolt connecting the rear mudguard to the rear of the frame on the same side. Fit support arm P200/P201 (remember, these are handed). Use the shock absorber bolt to attach the long horizontal arm, and the two ¼ bolts provided to attach the short upright arm to the mudguard. You will need to bend this to suit your guard. Repeat on the opposite side. The furthest two upright arms attach to the rack, using the set bolts provided. Reattach the dual seat. Make sure the rack is level and tighten all nuts.

### **Pannier kit -**

Remove the pillion footrest on one side.

Using the pillion footrests, fit the long support arms (P463 and P464), remembering these are handed, not only left and right, but also top and bottom.

Attach the top, rear of each long support arm to pannier ski on the rack.



# Craven Equipment

Inspired by Adventure Built for Everyday

