



# Craven Equipment

Inspired by Adventure Built for Everyday

Bike – BSA, D7/10/14/B175 & C15 1959-70

**The correct rack for these bikes is a 'W' rack**

The fitting kit is designed to mount the rack to the motorcycle. A secondary kit is required to hold panniers.

## Main fitting kit

Part Number	Qty	Description
P399	2	'F' Support arm BSA D7/10/14, Triumph T20B
P437	2	7/8 tube clip
41-0146	2	Distance piece - stainless steel
FA1476Q	2	Set bolt, M8 x 20, stainless steel
FA1477Q	6	Set bolt, M8 x 25, stainless steel
FA1040Q	2	Bolt, standard head, M8 x 30 (1-1/4"), stainless
FA1530Q	12	Nyloc nut, M8, stainless
S19-3Q	26	Plain washer, 5/16, stainless



# Craven Equipment

Inspired by Adventure Built for Everyday

## Pannier fitting kit

Part Number	Quantity	DESCRIPTION
FA1476Q	2	Set bolt, M8 x 20, stainless steel
FA1530Q	2	Nyloc nut, M8, stainless
P374	1	Support arm left hand BSA D7/10/14, Triumph T20B
P374A	1	Support arm right hand BSA D7/10/14, Triumph T20B
s19-3Q	4	Plain washer, 5/16, stainless

## Fitting the rack:- Specific notes about your kit

### Main kit

It is quite straightforward to fit the rack to the bike. Remove the seat and attach the loop stays as shown in Fig 1, using the spacers provided, and fasten the two-holed top of the clamp brackets (P493) so they hang below. The white arrow shows which bolt uses the thin M8 nut (see image below). Then attach the long support arms (P399) to top shock absorber bolts, so the base of the 'F' faces up and toward the rear, as shown. PLEASE NOTE the images show the old style support arms, which we have redesigned into one arm in an 'F' shape. We will update the images as soon as we are able.

Now attach the centre upright of the long stay to the rack. Finally attach the rack to the remaining two uprights of the support arms each side, clamping the loop stays to the long support using the shorter clamp side (P204). Tighten all the nuts up equally, making sure to keep the rack level as you go.

### Secondary fitting kit

This is only required to hold panniers. Remove the pillion footrest mounts. Attach the P374 & P374A long support arms to each side and refit the footrests. Using the nuts & bolts supplied, attach to the W rack along the outside edge against the skates on the bottom.

See 'General Fitting instructions' for step-by-step advice for fitting a rack and panniers to any machine.



# Craven Equipment

Inspired by Adventure Built for Everyday

Fig 1





# Craven Equipment

Inspired by Adventure Built for Everyday

Fig 2

