



Craven Equipment

Inspired by Adventure Built for Everyday

Bike – Moto Guzzi

The correct rack for these bikes is a 'L2' rack

The fitting kit is designed to mount the rack/topbox to the motorcycle only. A secondary kit is required should you want to hold panniers.

Included in the fitting kits:-

Main fitting kit

| Part Number | Quantity | DESCRIPTION |
|-------------|----------|--|
| 5058-26Q | 2 | 5/16 penny washer for 0574/8/9/0207, stainless |
| B156 | 6 | Spacer stainless 8x5/8x10 |
| B158 | 2 | Straight leg, front |
| FA1040Q | 2 | Bolt, standard head, M8 x 30 (1-1/4"), stainless |
| FA1041Q | 2 | Bolt, standard head, M8 x 40, stainless |
| FA1530Q | 4 | Nyloc nut, M8, stainless |
| S19-3Q | 4 | Plain washer, 5/16, stainless |

Pannier fitting kit

| Part Number | Quantity | DESCRIPTION |
|-------------|----------|--|
| FA1476Q | 2 | Set bolt, M8 x 20, stainless steel |
| FA1530Q | 2 | Nyloc nut, M8, stainless |
| P470 | 1 | Support arm right hand BSA A7, A10, A75, Royal Enfield |
| P471 | 1 | Support arm left hand BSA A7, A10, A75, Royal Enfield |
| S19-3Q | 2 | Plain washer, 5/16, stainless |



Craven Equipment

Inspired by Adventure Built for Everyday

Fitting the rack:- Specific notes about your kit

Main kit

1. Remove the large nut and bolts that secure the back of the dual seat
2. Remove the two nuts from the top shock absorbers, then remove the thick washers and fit the B158 straight legs (the circular end, see top arrow below), refit the top shock absorber nuts, but don't fully tighten
3. Offer the rack up and fit the M8 bolts through the round discs at the front of the rack, then a spacer, then through the support arm (B158) with a nut on the inside of the arm
4. Now attach the centre mount of the rack, this time it will be bolt, rack, spacer, support arm, spacer and then through the rear seat mounts. Use the large penny washers before the bolt passes through the seat support
5. Line the rack up in the desired position and tighten all nuts

Pannier Kit

1. Remove the pillion / silencer mount nut
2. Attach long support arms (which are handed, P470 and P471, see side arrow below) to this bolt
3. Fix the bolt and nut at the rear of this arm through the 'skates' on the bottom of the rack
4. Tighten all nuts

Fitting luggage :- See 'General Fitting instructions' for step-by-step advice for fitting a rack and panniers to any machine.



Craven Equipment

Inspired by Adventure Built for Everyday

