



Craven Equipment

Inspired by Adventure Built for Everyday

Bike – Vincent series B & C

This kit holds both panniers and / or topbox.

Included in the fitting kit:-

Part Number	Quantity	DESCRIPTION
21-5621	2	Bolt 1/4 CEI x 2"
4132-38	2	Shouldered nut
FA1051Q	1	Nut, Nyloc, M6, stainless
FA1457Q	1	Set screw, standard head, M6 x 40, stainless
FA1463Q	6	Bolt, standard head, M8 x 35, stainless
FA1476Q	2	Set bolt, M8 x 20, stainless steel
FA1041Q	2	Bolt, standard head, M8 x 40, stainless
FA1530Q	8	Nyloc nut, M8, stainless
P253	1	Vincent - Centre fixing stainless - frame at front
Rack-VIN	1	Vincent rack - Four black tubular pieces
S1-2Q	2	Nut 1/4 CEI26 - stainless
S19-2Q	4	Plain washer 1/4, stainless
S19-3q	16	Plain washer, 5/16, stainless



Craven Equipment

Inspired by Adventure Built for Everyday

Fitting the rack:- Specific notes about your kit

Main kit -

This kit is relatively simple to fit. It comprises four black tubular frames -

- Two side pannier rails, which are handed
- One top rack
- One rear support, U shaped
- A series of fastenings.

Firstly fit the spacer bar and nut assembly through the sidecar mounting hole under the front of the rear suspension, see Fig 1 and 2, then tighten.

Now to fit the rear 'U'-shaped support rail. Remove the 2 upper seat pivot bolts from the back of the seat. Replace the bolts with our two, longer, two inch 21-5621 bolts, ¼" nuts, washers and sleeve nuts, see fig 3 and fig 4 for location and order of fitment.

Use a thin spanner to hold the shoulder nut in place while nipping up the outside nut. This will allow the seat suspension to function correctly whilst the stepped nut will allow the U shaped support to also pivot. The tab in the centre of the 'U' should be facing upwards, in order to attach to the luggage rack later.

Next remove the pillion footrest and attach the side pannier rails, noting that they are handed, bending outwards from the bike. Use the M8 bolts (40mm and 35mm), nuts and washers to attach the rail plate to the footrest mount, see fig 5. **NOTE Series B Vincents use the top row of holes in the plate, series C uses the bottom row of holes.**

Attach the top side rail mounting point to the sidecar mount using the spacer bar fitted earlier, using the M8 x 20mm bolt and washer. Then loosely attach the top rack clevis to the U-shaped rear support centre tab using the M6 screw and nut. Then line-up and fasten the slotted skis of the rack to the side rails as fig 6.

Tighten all bolts.

Figure 7 shows the completed set-up.

If you have any issues, or your Vincent is not standard, please contact us for assistance.

Fitting luggage :- to fit luggage, please see our 'General Fittings' sheet. Contact us if yours is missing or download from our luggage section on the website.



Craven Equipment

Inspired by Adventure Built for Everyday

Fig 1



Fig 2





Craven Equipment

Inspired by Adventure Built for Everyday

Fig 3



From outside to in - Bolt, washer, seat bracket, stepped nut, Craven U-shaped support, washer, lock nut.

Fig 4





Craven Equipment

Inspired by Adventure Built for Everyday

Fig 5





Craven Equipment

Inspired by Adventure Built for Everyday

Fig 6





Craven Equipment

Inspired by Adventure Built for Everyday



Fig 7



Craven Equipment

Inspired by Adventure Built for Everyday

